

Align the door handle with the assembled base. Make sure the handle is leveled on the work surface. Use the set screw and hand-tighten the handle on both sides.

Hex key

BOTTOM

2″ O.C. MIN.



Determine the position and location for mounting on your surface. Drill your 4mm(5/32") diameter holes at 160mm (6-5/16") apart. (Note: For laminated glass door, 2" MIN. distance from the edge of the door is required.)



Assemble the base with (1) locking nut, (1)threaded rod, and (1) plastic washer at the back of the work surface. Align the assembly through the predrilled hole. Repeat the same assembly order from the front side. (Note: Make sure to hand tighten both sides of the assembly.)

