

PCS129

PROPRIETARY AND CONFIDENTIAL.
ALL DIMENSIONS HAVE A +/- 1/16" TOLERANCE UNLESS OTHERWISE SPECIFIED. WE DO NOT RECOMMEND DRILLING OR CUTTING ANY HOLES BEFORE RECEIVING A PRODUCT OR A PRODUCT SAMPLE.

⚠ WARNING ⚠

- For indoor use only.
- For use on a normally dry work surface.
- If any malfunction occurs, do not attempt to disassemble or repair.
- Avoid placing the unit in a high temperature environment or near fire.
- When the product is embedded, foreign matter such as debris and dust should be avoided from entering the outlets, USB-A and USB-C ports.
- For your safe use, do not contact with water, corrosive liquid, inflammable and explosive substance during the use of the product. If such a situation occurs, please pull out the power plug of the product out of the wall outlet immediately.
- This product completely is strictly prohibited to be exposed to overheat, under cold or humidity.

SPECIFICATIONS

- 6 ft. cord length.
- USB-A and USB-C ports are for charging use only.
- Table thickness is 12.50mm (1/2") MIN. to 80.00mm (3-5/32") MAX.
- Circuit breaker reset is located at the bottom of the unit.

MAINTENANCE AND CLEANING

- Always unplug before cleaning.
- Stay clear of electrical socket and USB ports.
- Do not use harsh chemicals or solvents.



TABLE OF CONTENTS




..... 1X PCS129



..... 1X Lock Ring



TOP VIEW




FRONT VIEW

PCS129


PROPRIETARY AND CONFIDENTIAL.
ALL DIMENSIONS HAVE A +/- 1/16" TOLERANCE UNLESS OTHERWISE SPECIFIED. WE DO NOT RECOMMEND DRILLING OR CUTTING ANY HOLES BEFORE RECEIVING A PRODUCT OR A PRODUCT SAMPLE.

1




Make a cut out in the desired location on your work surface. Allow enough clearance for unit operation. DO NOT place unit where cable is strained or trapped.

2




Install the PCS129 into the cut out and make sure it is fully leveled onto the work surface.

3



Guide the lock ring through the cable and secure the unit by turning the lock ring clockwise.

4



Press down on the pop-up mechanism to expose or hide the power outlets on the unit.