

## **MOCKETT**

PART # PCS64/2/USB

310.318.2491 • 800.523.1269 • www.mockett.com



1




Note:


Minimum clearance required under the work surface is 18".

Make a cutout in the desired location on your work surface. Allow enough clearance for unit operation. DO NOT place unit where the cable is strained or trapped.

2



3



Guide the cord through the cut out. Install the unit into the cutout, make sure it is fully level on the surface, and oriented to the appropriate side.

Screw threaded lock ring onto mounting collar by turning clockwise. Locking ring should rotate smoothly once properly engaged. If not, the locking ring may be cross-threaded - undo and try again.

4

Connect the unit into a nearby outlet.

## MAINTENANCE AND CARE:

- 1. Ensure unit is disconnected prior to cleaning.
- 2. Clean the unit with a damp cloth and dry immediately.
- 3. Do not use harsh chemical solvents.

## N WARNING /

- USB ports are for charging use ONLY.
- For indoor use only.
- If any malfunction occurs, do not attempt to repair.
- Do not insert foreign objects into power outlets.
- For counter top mounting.
- Risk of electric shock. (Do not connect to another relocatable power tap.)

