



PART #

PCS67T/WC


310.318.2491 • 800.523.1269 • www.mockett.com

NOTE:

- USB port is for charging use ONLY.
- 6 ft. cord
- Mobile device must be equipped with a wireless charging receiver (wireless charging accessories not included). Check mobile manufacturer for compatibility.
- Wireless output 5W Max.



Place the unit on the desired location of the work surface. Make sure the unit is fully leveled on the work surface.

2

Position the mobile device on the center of the charging area. The indicator light will blink a blue light to signify that the device is actively charging or the charging icon will activate on the device's screen. The indicator light will show a red light when the device is not aligned at the center of the charging area.