



TOP VIEW




NOTES:

1. Cord length 6 ft.
2. USB ports are for charging use ONLY.
3. Circuit breaker reset is located under the unit inside the data compartment.



FRONT VIEW



RIGHT VIEW