



PART #

WM39/40/SET


310.318.2491 • 800.523.1269 • www.mockett.com

**NOTE:**

- Some included parts are not required for installation. Please refer to Table of Contents.
- Min. table thickness is 1".
- Max. cord thickness is 14.65mm DIA. (9/16") for WM39/LINK.




















**RIGHT VIEW**




**TOP VIEW  
WM39/LINK**

132.00mm X  
90.75mm  
(5-3/16" X  
3-9/16")

**TABLE OF CONTENTS:**


	.....2 X WM40/Trough		.....2 X WM40/Bracket		.....2 X 3/4" Pan-head Screw
	.....4 X WM40/Clip		.....8 X 1-1/4" Pan-head screw		.....1 X WM40/Upper Cable clamp
	.....1 X WM39/40-CONNECT		.....2 X WM40/End cap		.....1 X WM40/Lower Cable clamp
	.....1 X WM39/Connector		.....2 X WM39/Magnet		.....50 X WM39/Link
	.....1 X WM39/Base		.....1 X WM39 Hook (Not required for install)		.....1 X WM39/QUAD (Not required for install)
	.....2 X 5/8" No.8 Wood Screw (Not required for install)		.....1 X 1" No.9 Button-head Wood Screws (Not required for install)		

1




Align and snap (2) WM40/Trough and (2) WM40/End caps.

2




Snap (4) of the WM40/Clip to the top edge of the trough.

3




Hook the (2) WM40/Bracket under the pivot on top of the clips.

4



Use (8) screws to secure the part under the work surface. (Note: Minimum set back from rear edge of the work surface is 2-1/2". Recommended minimum table thickness is 1".)


5



Pull the WM40/Clip out and WM40/Trough down to unhook the trough from the bracket. Place and guide wires in the trough; close when finished.


6

OPTIONAL




Use (2) screws to secure the cable in between upper and lower clamp assembly. Snap the assembly into the opening in the trough.

7




Determine orientation and push the WM39/40-CONNECT into one of the openings on the WM40 troughs.

8




Snap WM39 male post into female opening of WM39/40-CONNECT.

9




Determine overall length for travel distance of WM39 and snap pieces together to length. Male posts insert into female opening on underside. Choose one of three settings when snapping together.

10




Install WM39/Magnet to the WM39/Link posts. Make sure the work surface is a magnetic metal.

11



Connect WM39/Connector to WM39/Base and WM39/Link. Repeat for additional sides as needed from WM39/Base.

12



Push in the wing of WM39/LINK and slide cable in.