

PART #

PCS3/HW

310.318.2491 • 800.523.1269 • [www.mockett.com](http://www.mockett.com)

1. Route an oval hole 3-1/2" wide x 12" long. (Note: Masking tape may be applied over the area to help avoid chipping veneer or laminate.)
2. Lower PCS3/HW into place and route cord as needed. Position PCS3/HW so that the power cord faces the intended outlet, this is where cord will be routed. (Note: For a snug fit to the work surface, apply tape around the outside perimeter of the PCS3/HW.)
3. Install PCS3/HW into table cut out. Note: For extra copies of the template please visit our web site, <http://www.mockett.com/pdf/installation-sheets/PCS3-HW.pdf>

